

NOTE: The use of channel lock pliers is recommended to close the “S” hooks.

Place top of “S” hook to open from “rear.” Close slightly but leave enough space to slip over the barbed wire in the upper part of “S” hook. This will only need to be done the first time that the sign is used.

Close lower part of “S” hook tight, but do not crush on sign.



Sign should swing “free” and should be easy to move to another location , if necessary, without changing the shape of the “S” hooks.